HIMALAYAN

MANUAL

FOREWORD

Thank you for choosing the Royal Enfield Himalayan.

Your new motorcycle is the product born from Royal Enfield's vast experience of riding in the Himalayas since decades, from exhaustive testing in all conditions, and our continuous striving for superior reliability and performance.

Please read this Owner's Manual carefully before riding so that you will be thoroughly familiar with the proper operation of the Himalayan's controls, its features and capabilities.

To ensure a long and trouble-free life for your motorcycle, give it the proper care and maintenance described in this manual. This Owner's Manual should be considered a permanent part of your motorcycle and should remain with it even if your motorcycle is subsequently sold.

The Himalayan features a Tripper $^{\mathbb{T}}$ navigation system, powered by Google Maps and the Royal Enfield App. You can use it to connect your smartphone with the motorcycle through Bluetooth. To use the Tripper $^{\mathbb{T}}$ and to explore the many rides around you, install the Royal Enfield App and follow the steps to register your Himalayan.

-Team Royal Enfield.

NOTICE

All information in this manual is based on the latest product information available at the time of publication. Due to continuous improvements, there may be discrepancies between the information in this manual and your motorcycle. Royal Enfield reserves the right to make production changes at any time without prior notice and without incurring any obligation to make the same or similar changes to motorcycles previously built or sold.

All images shown are for reference to explain and need not to be exactly the same on the model you own. Technical specifications are subject to change without prior notice.

"© Copyright 2021 Royal Enfield (A unit of Eicher Motors Ltd.). All Rights Reserved. No part of this manual shall be copied, distributed or otherwise dealt without the express permission in writing of Royal Enfield".

Disclaimer

- Wash the motorcycle only with plain water. Do not use any cleaning agents or detergents, especially on painted surfaces, as it will cause discoloration and damage to the paint.
- 2. Do not polish your motorcycle as it will increase the gloss level and damage the paint.
- 3. Scratches or marks on painted / plastic surfaces cannot be removed OR touched up.
- 4. Warranty is not applicable for discoloration of the Silencer & Exhaust pipe, as it is a natural process that will happen during usage.

Part No. RAMO0264/A / Qty. 500 / Jan. 2021 / 10134

CONTENTS

Personal and Motorcycle Information	4	Environment Care 72
Technical Specifications	5	Periodical Maintenance Chart
Recommended Lubricants	12	Tools Kit
Safety Definitions	13	Minor Maintenance Tips
Motorcycle Identification Numbers	14	Long Trip Precautions 109
Location of Key Parts	17	Shock Absorber 110
Operation of Controls	20	Off Roading 111
Pre-Operational Checks	51	Washing Procedure 112
Safe & Happy Riding	52	Storage Precautions
Cargo & Accessories	56	Wiring Diagram 119
Rules of the Road	58	Trouble Shooting 120
Running in Period	61	Warranty Terms & Conditions 124
Warning Indications & Safety Systems	62	Emission Warranty 127
Starting	66	EVAP
Gear Shifting, Riding & Stopping	68	Service / Maintenance Record
Parking	70	Notes
		Royal Enfield Himalayan 03

PERSONAL & MOTORCYCLE INFORMATION

Name																				
Door No./Street																				
Locality/Town																				
City	Country																			
Contact	Res:	Res: Off:																		
	Mob	Mobile : Email :																		
Licence No.	Valid Till :																			
Model	Color :																			
Engine No.																				
Vin No.																				
Tyre make	Fror	nt :		•			•			Rea	r:							•		
Tyre Nos.	Front : Rear :																			
Battery make					Battery No.															
Sold by																				
Date of Sale																				

ENGINE		Air filter element	Paper element		
Engine Type	9	Lubrication	Forced Lubrication, Wet sump		
	Air cooled, Fuel Injection	Engine oil capacity	2.3 L (Initial fill only),		
Bore	78 mm		1.6 - 1.8 L (Subsequent Refills)		
Stroke	86 mm	Engine oil grade	SAE 15W 50 API SL Grade		
Displacement	410.94cc		JASO MA 2 Semi Synthetic		
Compression ratio	9.5:1	Cooling	Air cooled with Oil cooler		
Max Power	24.3 bhp (17.88 KW) @ 6500 rpm	IGNITION SYSTEM	<u> </u>		
Max Torque	32 Nm @ 4250 <u>+</u> 250 rpm	Ignition system	Electronic ECU / Variable		
Idle RPM	1250 <u>+</u> 100 rpm	Spark plug	Bosch - UR5CC		
Starting System	Electric Start	Spark plug gap	0.7 to 0.8 mm		
			— Royal Enfield Himalayan 05		

TRANSMISSION

Primary drive Gear 4th Gear 4th 1.173:1

Primary ratio 2.312:1 5th Gear 5th 1.000:1

Gear box 5 Speed, Constant Mesh Secondary Drive 5/8" Chain & Sprocket

Gear Ratios Secondary Ratio 2.533:1

2nd Gear 2nd 1.833:1

CHASSIS

Frame	Half duplex split cradle				
Suspension Front	Telescopic, Hydraulic Damping, Front wheel travel : 200 mm Swing arm with Linkage type	Tubed and Steel Rim	Standard Tyre	Replacement Tyre: Replace with Standard Tyre or below mentioned Tyre	
	Hydraulic damping Mono shock, Rear wheel travel : 180 mm	Front	Make, Type : Pirelli	Make, Type : CEAT	
Brakes			Size:	Size:	
Brake system	Dual Channel ABS (Switchable to Single channel ABS -		90/90-21 54H	90/90-2154S	
	Rear Wheel ABS control deactivation)	Rear	Make, Type : CEAT / I	Pirelli	
Front Disc	300mm Dia disc.		Size: 120/90-17 64S		
Rear Disc	240mm Dia disc.		,		

CAUTION

- The use of petrol containing more than the specified ethanol may cause the fuel tank corrosion & paint damage and may also damage the rubber tubes in the fuel line as well.
- It is recommended to use only unleaded petrol, as leaded petrol may cause damage to the catalytic converter.

Tyre Pressures

Solo

Front 25 PSI / 1.75 Kg/cm²

Rear 32 PSI / 2.25 Kg/cm²

With Pillion

Front 27 PSI / 1.89 Kg/cm²

Rear 34 PSI / 2.39 Kg/cm²

Steering lock In built

Fuel Type Unleaded Gasoline

Ethanol Content E10 or less

Minimum Octane 91 RON (Research Octane rating Number) or Higher

Fuel tank capacity* ... 15 ± 0.5 litres approx *

Low fuel warning Fuel Gauge (Red zone) 5.5 ± 0.5 litres approx.*

Dead stock 0.5 litre approx.*

(unusable fuel)

* The above values are approximate and the actual capacity may vary with each fuel tank.

ELECTRICALS

Flywheel magneto 221W @ 1500 rpm

Generation Alternator, III Phase

System 12V - DC

Battery 12V - 8 AH Maintenance Free

Head lamp 12V, H4-60/55W - BULB

Tail lamp / Brake lamp .. 12V - 4/1W LED

Licence Plate illuminator 12V - LED

Front position lamp 12V - LED

Speedometer lamp 12V - LED

Hi beam indicator 12V - LED

Neutral lamp telltale 12V - LED

Turn signal telltale 12V - LED

Turn signal 12V, 10W * 4 Nos.

Horn 12V, 2.5 Amp.

Starter Motor 12V, 0.7 KW

Instrument Cluster Digital cluster with main and

compass LCD

Side Stand Indicator LCD Indication

Malfunction Indicator ... 12V - LED

ABS Indicator 12V - LED

▲ WARNING

Using bulbs / electrical gadgets other than specified rating may lead to overloading / erratic behaviour / premature failure of electrical system.

Modifications or fitments which are not approved by Royal Enfield, will seriously affect the performance of the vehicle and will render the warranty void.

TECHNICAL SPECIFICATIONS DIMENSIONS WEIGHTS Length 2190 mm Kerb weight (90% fuel & oil) 199 Kgs. Width 840 mm Height 1370 mm Wheel base 1465 mm Ground clearance. 220 mm Saddle Height 800 mm

- Values / Dimensions mentioned above are for reference only.
- In view of continuous improvements being done on our motorcycles, the specifications are subject to change without prior notice.

RECOMMENDED LUBRICANTS

	ENGINE OIL					
Grade	SAE 15W 50 API SL Grade JASO MA 2 Semi Synthetic		C			
Capacity	2.3 Ltrs. (First Fill only) 1.6 - 1.8 Ltrs. Approx. (during oil & filter element replacement in periodical maintenance)		c			

FRO	NT FORK OIL	BRA	KE FLUID
Grade	10W/Fork Oil (Viscosity range 35)	Grade	DOT 4
Capacity	455 ml/leg	Capacity	Front / Rear : 100ml

NOTE

Oil level should be up to "MAX" level. Do not overfill as it will affect the clutch functioning.

CAUTION

Using Non Recommended / In-Correct oils, can cause serious damage to the moving parts, affect performance of the motorcycle AND void the warranty.

NOTE

Recommendation subject to change without notice.

SAFETY DEFINITIONS

The information given under the titles: Warning, Caution and Note are for your safety and for the care and safety to your motorcycle and others. Please read these carefully and if disregarded may result in injury to yourself or others and damages to the motorcycle.



! WARNING

Indicates a potentially hazardous situation. Disregarding this message may result in injury to rider or other persons.

CAUTION

This message if disregarded may result in damage to the motorcycle.

NOTE

Indicates important and useful messages for clearer understanding.

 $All\,Images\,shown\,in\,subsequent\,pages\,are\,for\,reference\,to\,explain\,and\,need\,not\,to\,be\,exactly\,the\,same\,on\,the\,model\,you$ own.

The VIN is a 17 digit number punched of	n the right side ste	ering head	tube and i	in the info	rmation	plate rivet	tedtothe	frame down tube
Sample VIN :	ME3	хх	XX	Х	Χ	G	Χ	XXXXXX
Manufacturer's code			ĺ		ĺ			
Type of Frame Type of Engine								
Variant / Version								
Ignition System								
Transmission Type								
Production Year (2021 : M, 2022 : N, 2023 : P) Assembly factory (C-Chennai, K-Kanchipuram, V-Vallam Production Serial No.								

MOTORCYCLE IDENTIFICATION NUMBERS

FRAME NUMBER

Punched on steering head tube right side.



MANUFACTURER STATUTORY LABEL

Affix in Frame down tube.




CAUTION


It is illegal to tamper with OR alter the VIN / Engine numbers of the motorcycle as it will not only against the law BUT will render the vehicle registration AND warranty VOID.

MOTORCYCLE IDENTIFICATION NUMBER - DETAILS

The engine number is punched on the left hand side Crankcase. It is the means of identification of the Engine and its production details. Please do not tamper with the engine number as it is prohibited by law.



LOCATION OF KEY PARTS



- 1. Horn Button
- 2. Turn Signal Switch
- 3. Head Lamp Dip Switch
- 4. Rear View Mirror Left Side
- 5. Instrument Cluster
- 6. Wind Shield
- 7. Tripper
- 8. Rear View Mirror Right Side
- 9. Engine Stop Switch
- 10. Electric Start Switch
- 11. Fuel Tank Cap

LOCATION OF KEY PARTS



- 1. Front Trafficator Right Side
- 2. Horn
- 3. Oil Level Window
- 4. Rear Brake Pedal
- 5. Rider Foot rest Right Side
- 6. ABS Module
- 7. Pillion Foot rest Right Side
- 8. Rear Trafficator Right Side

LOCATION OF KEY PARTS



- 1. Front Trafficator Left Side
- 2. Head Lamp
- 3. Tail Lamp
- 4. Rear Trafficator Left Side
- 5. Licence plate illuminator
- 6. Pillion Foot rest Left Side
- 7. Side Stand
- 8. Center Stand
- 9. Rider Foot rest Left Side
- 10. Gear Change Lever
- 11. ABS Module
- 12. Canister

STEERING LOCK

LOCKING:

- Turn handle bar to extreme left or right position.
- Switch "OFF" ignition, gently depress key and turn anticlockwise further till steering is locked and remove key.



UNLOCKING:

■ Insert key, turn clockwise to ignition "OFF" position. If required, gently shake handle bar to help unlock steering easily.

CAUTION

Do not force or attempt to lock / unlock steering if the handle bar is not in extreme left or right side. Failure to adhere to this caution will damage the lock and also cause the key to bend or break.



WARNING

 $After unlocking \, steering \, AND \, before \, starting \, engine, \, check$ the handle bar free movement by turning to both left and right sides, several times.

Failure to do so may cause unstable riding, leading to a potential accident, resulting in serious injury to both rider and other road users, besides causing severe damage to the motorcycle.

FUEL TANK CAP

OPENING:

- Lift flap and insert key.
- Turn key clockwise to enable cap to unlock and spring up.



NOTE

Key CANNOT be removed when fuel tank cap is open.

CLOSING:


- Gently depress cap till it is firmly locked in place and key can be removed.
- Remove key and close flap.

WARNING

DO NOT overfill the fuel tank, stop filling when the fuel reaches bottom of anti-splash plate. Because fuel expands when it heats up, heat from engine or the sun can cause fuel spill out of fuel tank.

Petrol is highly explosive. Please ensure there are no open flames or sparks nearby while refueling and fill fuel tank only in a well ventilated area.

Please ensure petrol does not spill on painted surfaces. Wipe immediately incase fuel spills over as otherwise it will leave a permanent stain on the painted surfaces.



IGNITION SWITCH

Ø OFF

 \bigcirc ON



NOTE

Key can be removed only if ignition is in "OFF" or steering is locked.



DO NOT switch "OFF" ignition while riding the motorcycle. Doing so can cause a potential accident, resulting in serious injury to both rider and other road users, besides causing severe damage to the motorcycle.

ENGINE STOP SWITCH

Engine "OFF"

Engine "ON"



E-START SWITCH

Press & hold till engine



HAZARD LIGHT SWITCH

A Hazard Light "ON"

OFF

WARNING

- Turn signals do not work when the hazard light switch
- All the trafficator lamps will flash simultaneously.

HORN





DIMMER SWITCH

- **■** High beam
- Low beam



DAY FLASH

Press for Head Light Flash.



TURN SIGNAL SWITCH

Left turn signal "ON"

1 "OFF" (Push to cancel)

Right turn signal "ON"



RIDER & PILLION SEAT

- Locate key on left side & turn clock wise Lift pillion seat and remove.
- Lift front seat from rear & remove.




DOCUMENT HOLDER

- Useful for storing motorcycle documents and owners manual.
- Remove the pillion Seat.
- Gently press on top to release the tabs from the frame and open slightly.



- To completely remove, release the bottom tabs from the frame by pulling out gently.
- When washing the motorcycle, be careful not to flood this area with water.

INSTRUMENT CLUSTER EURO V



- 1. Main LCD
- 2. Speedometer (KM major)
- 3. Tell tales
- 4. Tachometer
- 5. Mode button
- 6. Select button
- 7. Compass display
- 8. Fuel gauge
- 9. ABS Switch
- 10. ABS Indicator Lamp

26 | Royal Enfield Himalayan

INSTRUMENT CLUSTER EURO V - UK MODEL




Main LCD
 Speedometer (Miles major)
 Tell tales
 Tachometer
 Mode button
 Select button
 Compass display
 Fuel gauge
 ABS Switch

10. ABS Indicator Lamp

- Royal Enfield Himalayan | 27

A. MAIN LCD



- 1. Clock
- 2. Ambient Temperature
- 3. Service reminder
- 4. Odometer
- 5. Trip Value (A/B & F), AVG speed A/B
- 6. Side Stand indication
- 7. Gear position indication

CLOCK

- Display in 12 hour format with AM/PM indication.
- Will reset to 12:00 AM when battery is disconnected.



CLOCK SETTING

Function	Switch	Pressure time (sec)	Action
	SELECT & MODE pressed with No Speed input	≥ 3 sec	In ignition key 'ON' position (when vehicle not running) Enters into clock setting mode and hour digits starts to blink
	SELECT	<1sec	Hours value shall increment by 1 accordingly for no of press
CLOCK [SELECT	≥ 3 sec	Hour value saved and minute digits starts to blink
SETTING	SELECT	<1sec	Minutes value will increase by 1 by each press of the "Select" button
MODE	SELECT	≥ 3 sec	Minute value save and PM / AM digits starts to blink
	SELECT	<1sec	PM / AM is interchangeable by each press of the "Select" button
	SELECT	≥ 3 sec	PM / AM save and exit from clock set mode
	NO ACTION	20 sec	Auto exit without saving changes and continue with previous setting

WARNING

NEVER attempt to operate the select or reset buttons while riding the motorcycle. Failure to do so may cause loss of concentration and unstable riding, leading to a potential accident, resulting in serious injury to both rider and other road users, besides causing severe damage to the motorcycle.

AMBIENT TEMPERATURE INDICATION

- Ambient temperature display can be changed from Celsius to Fahrenheit and vice versa.
- The temperature indication may increase during vehicle riding / engine "ON" condition due to increase of engine temperature.
- Ambient temperature indication tolerance is ± 2°C.



NOTE

The ambient temperature valve should be referred to only when the engine is switched "OFF" and the engine is in cold condition.

The temperature displayed will be higher if the engine in running or immediately after it is switched "OFF" since the sensor will only pickup the higher temperature surrounding it.

TEMPERATURE UNIT CHANGEOVER

Temperature sensor push button management.

Required button

■ Mode



Function	Button	Pressure time (sec)	Action
TEMPERATURE UNIT CHANGE OVER	MODE	≥10 secs	In ignition key "ON" position, long press and hold "MODE" button for period ≥ 10 secs to reset temperature units from degree Celsius to Fahrenheit and vice versa.

I. ABS SWITCH - ACTIVATION PROCEDURE

- 1. Ignition switch "ON" condition
- 2. Vehicle stationary
- 3. Press ABS switch for (3-5

Single Channel ABS mode is activated (if, enabled): Rear ABS function will not work. Front wheel ABS will only work.

Procedure to Reset to Dual channel: Ignition switch reset*, vehicle will return to default dual channel ABS mode.



ABS switch

Dual Channel ABS mode (Default): ABS will work on both wheels.

*Ignition key Reset: Turning ignition switch from "OFF" to "ON".

CAUTION

If Single channel ABS mode enabled, ABS only controls the front wheel. The rear wheel is not controlled by ABS and may lock during braking maneuvers.

J. ABS INDICATOR LAMP

■ ABS indicator lamp continuously "ON" during initial check up (until or after vehicle running for a after vehicle running for a particular distance/speed)

ABS Indicator lamp lights up is indicate Status or and will turn "OFF" if system is ok, then will light system is ok, then will light up again in case of any ABS system malfunction.



■ Single channel mode indication Single channel Activation with ignition key reset*: ABS tell tale will blink thrice to indicate activation, followed by ABS tell tale continuous "ON", once the vehicle is ride more than 5 kmph, ABS tell tale will blink continuously.

Single channel Activation without ignition key reset*: ABS tell tale will blink continuously.



*Ignition key Reset: Turning ignition switch from "OFF" to "ON".

SERVICE REMINDER

- Service reminder is provided to remind about service
- Spanner symbol will flash till vehicle is serviced at service centre.



- Service reminder can be reset ONLY by authorised personnel at service centre after service is completed.
- Service reminder symbol will flash on as per below distance input from odometer.
 - i) 1st service 450 kms or 279.6 mile.
 - ii) 2nd service 4900 kms or 3044.7 mile.
 - iii) from there on for every 5000 kms or 3106.85 mile from previous value (ex: 9900 kms or 6151.5 mile, 14900 kms or 9258.4 mile etc.)

WARNING

DO NOT use high pressure water jet directly on instrument cluster for cleaning. Use only water spray cleaning and wipe it with soft dry cloth.

4. ODOMETER

■ Displays the cumulative kilometers the vehicle has covered.



TRIP A/B & AVG SPEED A/B


- Trip A/B indicates distance travelled in particular trip.
- Avg A/B indicates average speed of vehicle in particular trip mode.



Function	Switch	Pressure time (sec)	Action
TRIP A	SELECT	<1sec	In ignition key "ON" position, Move to: AVA A
	SELECT	> 2.5 sec	TRIP A/AVG A RESET
AVG A	SELECT	<1sec	Move to: TRIP B
	SELECT	> 2.5 sec	TRIP A/AVG A RESET
TRIP B	SELECT	<1sec	Move to: AVG B
	SELECT	> 2.5 sec	TRIP B/AVG B RESET
AVG B	SELECT	<1sec	Move to: TRIP A
	SELECT	> 2.5 sec	TRIP B/AVG B RESET

TRIP "F" MODE

- The word, Trip "F" will flash when the Trip "F" mode is
- Trip "F" is provided to measure distance travelled by the vehicle when fuel level in the vehicle is 5.5±0.5 lts. in the fuel tank so that the rider can plan fuel filling accordingly based on his trip requirements, Trip "F" will get activated when needle on fuel gauge enters the red zone.



- Trip "F" mode would come into function automatically.
- Trip "F" mode would de-activate automatically if fuel is filled above 5.5 ± 0.5 lts.
- During Trip "F" mode rider can toggle between Trip A/ B but mode will return automatically to Trip "F" after 25±5 secs.

NOTE

 Trip "F" will stop displaying at approximately 90 ± 5 seconds AFTER fuel level in tank is above 5 ± 0.5 litres, side stand is fully retracted AND Ignition is switched "ON".



NEVER attempt to operate the select or reset buttons while riding the motorcycle. Doing so may cause loss of concentration and unstable riding, leading to a potential accident, resulting in serious injury to both rider and other road users, besides causing severe damage to the motorcycle.

6. SIDE STAND INDICATOR

■ Indicates when side stand is extended.




GEAR POSITION INDICATION

- Displays the gear position in which the vehicle is traveling.
- When in neutral the indication will be "O".
- When in gear the appropriate number between 1 to 5 will be displayed.



C. TELL TALES

- 1. Turn Left : Left turn signal "ON".
- 2. Turn right : Right turn signal "ON".
- 3. Neutral: Transmission is in Neutral.



40 | Royal Enfield Himalayan

- 4. Low Battery Indication: Indicator will glow continuously if ignition switch is "ON" & engine is not running. Indication will switch off as soon as engine is started. If battery voltage is below 12 V, indicator will glow continuously indicating a low battery.
- 5. High Beam Indication : Head lamp high beam "ON".
- 6. EMS Malfunction Indication:
 - Will be illuminated as soon as ignition & stop switch are "ON" and will go "OFF" after the engine is started.
 - Will remain continuously "ON" incase of any malfunction of the EMS.

7. ABS MIL: Will be continuously "ON" during initial check up (until or after vehicle running for a particular distance / speed) and will turn "OFF" if system is ok, then will light up again in case of any ABS system malfunction.

CAUTION

DO NOT run motorcycle incase the malfunction remains "ON" continuously as it can cause severe damage to the ECU & Sensors. Please visit the nearest authorised Royal Enfield dealer to diagnose & rectify the defect in the EMS.

D. TACHO METER

- 1. Indicates the RPM at which engine is working.
- 2. Useful for right selection of gear with respect to engine RPM.



WARNING

- Do not run engine with gears in neutral as RPM will go beyond red zone.
- Do not ride motorcycle in lower gears with high acceleration as it will cause RPM to start to red zone & affect the main parts inside engine.

G. COMPASS LCD

- Useful for Navigation during riding.
- Text indicates heading direction of vehicle. (N, S, E, W, NE, NW, SE, SW)
- Arrow will always point to North.
- Eg. if heading Northwest, text will display NW and arrow will be in top right corner to indicate North.



CAUTION

- 1. Avoid using magnetic key chains, magnetic / ferrous materials or electronic components with interference around cockpit area to avoid malfunctioning of digital compass.
- 2. If compass LCD enters into calibration mode ("CA" flashing) ride vehicle in "8" direction slowly to calibrate the compass or approach nearest authorised service centre for assistance and proper calibration.
- 3. Indication fluctuation during riding is normal operation due to impact of road irregularities.
- 4. Compass indication tolerance is $\pm 45^{\circ}$.



DO NOT focus on the compass while riding. Doing so many cause loss of concentration and unstable riding, leading to a potential accident, resulting in serious injury to both rides & other road users besides causing severe damage to the motorcycle.

H. FUEL GAUGE

- Indicates fuel level in tank.
- The fuel pointer enters red zone, if the fuel level in the fuel tank is approximately 5.5 ± 0.5 litres.



WARNING

Do not use the motorcycle for long duration with the fuel indication in red zone. Refuel at the earliest.

Failure to do so may cause the motorcycle to run out of fuel and get stranded, in addition to causing serious damage to the fuel pump.

CAUTION

- DO NOT run motorcycle incase the ABS Indicator lamp continuously "ON".
- The ABS indicator blink continuously to indicate Single channel ABS mode is enabled.

TRIPPER



Tripper is being provided to have turn by turn Navigation on motorcycle to help riders to have a hassle free riding without handling the smartphones, This device works based on Bluetooth connectivity with navigation search based on RE Mobile app with the support of Google Maps.


Device is capable of showing turn by turn navigation on a custom designed round color TFT with uniquely designed arrow font designed intuitively for ease of riding.

Background display can be switched between day mode and night mode which can be selected by riders from RE Mobile app.

Features:

- Turn by turn navigation with primary turn, secondary turn
- Distance to next turn, distance to destination or Estimated Time of Arrival (ETA).
- Clock display (in case of no connectivity, no navigation input or after destination is reached).
- User can select day and night mode (through RE mobile app only).
- Low battery indication.

46 | Royal Enfield Himalayan




- Primary direction or next turn: Indicates the next turn to be taken along with the distance.
- Distance to next turn: Shows the distance to next turn.
- Secondary direction or next to next turn: Indicates the next turn to be taken after the primary direction, will be shown only when primary turn is less than 100 mts, if there is no turn the display will be blank in this region.
- Distance to destination or ETA: Shows the total distance to destination or estimated time of arrival (based on user selection from RE Mobile app).

Smartphones compatible version to use RE Mobile app:

- Compatible with Android and iOS.
- Android support: Current version 2.
- iOS support: Current version 1.
- Connectivity control only through RE Mobile app.

TRIPPER - DISPLAY FLOW SEQUENCE



NOTE

- After every Ignition "ON" cycle tripper will be in discoverable mode for 120 secs.
- Incase there is no connection established within 120 secs. display will enter into clock mode, to re-initiate connection Ignition "OFF-ON" cycle to be repeated.
- During Navigation mode if there is no input from smartphone for 5 secs, Bluetooth connection will be terminated to avoid power draw and will display clock.
- Bluetooth connection can be terminated by end user also by closing the mobile application.
- For first time pairing user needs to enter the secured pin shown on tripper through RE Mobile app to setup

the device, after that auto-pairing will happen if same device is connected.

- Everytime the tripper is paired the clock time will sync with mobile time after which it will continue to run with internal clock even in case of disconnection, there will be time difference between time shown on instrument cluster and tripper customer needs to update cluster clock inline with time shown on tripper as and when required as mentioned in push button management of cluster.
- Do not apply or use gasoline / petrol related fluids for cleaning or wiping on instrument cluster or Tripper, as it may result in permanent damage to the same.

CAUTION

- Ensure ignition is "ON" and display is in powered while establishing connection.
- Ensure first time pairing is done in isolated environment to avoid cross connections (one time).
- Day and night mode is user selectable only, will not change over automatically to be selected during night driving to avoid rider distraction.
- Bluetooth connection can be established only through RE Mobile app.
- Ensure bluetooth and location settings are turned always "ON" before usage.
- Disable battery optimisation settings / low battery cutoff setting of smartphone for Navigation to work in low battery mode.

- RE Mobile app works only with Android (Current version 2) and iOS (Current Version 1) versions, for other lower versions performance lag can be expected.
- Tripper Bluetooth version is V4.2.
- Tripper time display may have a mismatch with actual time displayed in mobile device once the bluetooth connectivity is lost.
- RE Mobile app works with bluetooth version 4.2 and N+1.0, for other lower versions performance lag can be expected.
- Check for network signal strength in case of navigation lag.
- Check for data speed in case of navigation lag, Navigation system performance is better in 4G band compared to other lower versions.
- Calibrate mobile phones frequently for more GPS accuracy & location accuracy is dependent on.

PRE OPERATIONAL CHECKS

- 1. Adequate fuel in fuel tank for the journey planned.
- 2. Tyres inflated to correct pressure.
- 3. No side wall cracks, cuts or abrasions in the front and rear
- 4. Rear chain for proper tension and sufficiently lubricated.
- 5. Engine Oil level.
- 6. Control cables, inner, not damaged, frayed or broken. Clutch and accelerator controls working smoothly.
- 7. Front and rear brake efficiency and free play in Front and Rear Brake levers.
- 8. Hydraulic oil level correct in both front and rear master cylinders.
- 9. Free movement of handle bar to left and right sides.
- 10. All electrical controls, horn working correctly.

- 11. Head lamp, tail lamps, brake lamps and indicator lamps working correctly.
- 12. Front and rear wheel axle nuts tightened properly to
- 13. Front and rear wheel spokes having proper tightness, no loose or broken spokes.
- 14. All fasteners are tight to required torque.
- 15. Engine idling correctly and smooth.
- 16. No abnormal noise / leak from engine.

WARNING

For your personal welfare and safety, these preoperational checks should be performed periodically. Failure to do so may affect safe operation, damage your motorcycle and could result in an accident causing serious injury.

SAFE&HAPPY RIDING

- Please read this manual carefully to get to know the motorcycle and its maintenance schedules.
- Please exercise utmost caution while refueling. Open the lid carefully and slowly. Refuel only in a well ventilated area with the ignition switched "OFF".
- Gasoline is highly explosive and inflammable. DO NOT smoke or refuel if there are any naked flames or sparks nearby. Switch "OFF" mobile phones and other hand held electronic devices.
- Know and respect the rules of the road. Please be a safe rider for your own safety and for other road users.
- Please ride your motorcycle defensively. Remember a motorcycle does not afford the same protection as an automobile.

- Ride only at moderate speeds and out of traffic until you have be come familiar with the handling characteristics of your motorcycle under all conditions.
- DO NOT exceed the legal speed limit. Always reduce speed when poor driving conditions exist. Use extra caution when approaching and passing through intersections, since intersections are the most likely places where accidents happen.
- Ride where other motorists can easily spot you. Please do not ride in another motorist's "blind spot".
- Always signal well in advance before turning or changing lanes. Make sure that other motorists can see your signaling and slow down.

SAFE & HAPPY RIDING

- Never ride under the influence of alcohol or other drugs that might affect your riding skills reflex.
- When carrying a pillion rider, it is your responsibility to instruct them on proper riding procedures and riding gear.
- If you are an inexperienced rider we recommend that you obtain formal training on correct motorcycle riding techniques. New riders should gain experience under various conditions while driving at moderate speeds. Pay strict attention to road surfaces and wind conditions.
- DO NOT allow other individuals, under any circumstances, to operate your motorcycle unless you

know they are experienced, licensed riders and are thoroughly familiar with the operating conditions of your motorcycle.

RIDING GEAR

- Motorcycle riding pants and jacket fitted with certified Armour.
- Motorcycle riding boots.
- Motorcycle riding gloves.
- ISI, DOT or SNELL certified helmet as applicable for rider and pillion.
- Wear a brightly colored jacket.

SAFE & HAPPY RIDING

- Never wear loose-fitting clothes; otherwise they could catch on the control levers, footrests, or wheels and cause injury or an accident.
- Always wear protective clothing that covers your legs, ankles and feet. The engine or exhaust system become very hot during or after operation and can cause burns.

CAUTION

Avoid any contact with the exhaust system. The exhaust system gets very hot and remains hot for a long time after parking the motorcycle. Wear clothing that will completely cover the legs while riding. Failure to do so may result in serious burn injuries.

54 | Royal Enfield Himalayan

SITTING POSTURE

Correct sitting posture is a must for stable and safe riding.

- Sit with your shoulders completely relaxed.
- Do not lock your elbows and retain them at a slight bend to enable maneuvering.
- Hold the handle grip close to its inner end.
- Lightly grip the fuel tank with your knees.
- Keep your toes in "straight ahead" direction.
- Before turning, look extensively in the rear view mirror, without turning your head.

SAFE & HAPPY RIDING

BRAKING

- Apply front and rear brakes gently and simultaneously for maximum braking efficiency.
- Please use utmost caution while applying brakes, especially while riding under wet or bad road conditions.

WARNING

The hydraulic disc brakes fitted on your motorcycle requires very less effort. Applying any one of the brakes suddenly may lock the wheels. Failure to adhere to this warning may cause loss of control on the motorcycle, leading to a potential accident, resulting in serious injury to both rider and other road users, besides causing severe damage to the motorcycle.

! WARNING

Brake pad wear will be increased if the motorcycle is used frequently off-road. Always inspect the brake pads more frequently if the motorcycle is used off-road $\&\, replace\, the$ brake pads before they become worn to or beyond the minimum service thickness. Riding the worn brake pads may reduce braking efficiency, leading to loss of motorcycle control and an accident.

DO NOT place the foot on the brake pedal while riding unless braking is required. Because this will lead to premature wear of brake pad.

CARGO & ACCESSORIES

LOADING

- Please do not fit Non OE or Non genuine accessories as they may cause damage to the motorcycle and also affect the riding and handling of the motorcycle.
- Please ensure cargo is securely strapped to the rear and sides of the motorcycle and do not become loose or shift while riding.
- Ensure the weight is distributed evenly on both sides of the motorcycle.
- Do not carry excessively heavy or huge cargo on the motorcycle.
- The permissibly weight of the cargo that can be strapped to the luggage carrier is 3.5 Kgs.

■ Do not hang any items on the handle bar and luggage carrier while riding which will lead to damage for the parts nearby.



WARNING

Please exercise utmost caution while carrying cargo or luggage on the motorcycle. Failure to adhere to the above precautions can cause loss of control on the motorcycle, leading to a potential accident, resulting in serious injury to both rider and other road users, besides causing severe damage to the motorcycle.

Total weight of the rider and any passenger, accessories and luggage must not exceed the maximum load limit.

CARGO & ACCESSORIES

CAUTION

Exhaust gases contains poisonous carbon monoxide and chemicals, known to cause Cancer, Birth defects or other reproductive defects. Please park the motorcycle only in a well ventilated area and do not stay in the same place where the motorcycle is parked, especially when the engine and exhaust system are hot.



WARNING

DO NOT tow a disabled motorcycle. The steering and $hand ling \, of \, the \, motor cycle \, will \, be \, impaired \, due \, to \, the \, force \,$ of the towline. Towing a motorcycle can cause loss of control on the motorcycle, leading to a potential accident, resulting in serious injury to both rider and other road users, besides causing severe damage to the motorcycle.



MARNING

DO NOT attach a trailer to the motorcycle Attaching a trailer can cause loss of control on the motorcycle, leading to a potential accident, resulting in serious injury to both rider and other road users, besides causing severe damage to the motorcycle.



WARNING

Max load on grab rail not to exceed 7 Kg.



RULES OF THE ROAD

- Be sure your number plate is installed in the position specified by law and is clearly visible at all times.
- Ride at a safe speed that is consistent with the type of road surface you are on. Pay strict attention to whether the surface is:
 - Dry
 - Oily
 - Icy
 - Wet
- Watch for loose debris, such as leaves, slippery substances or loose gravel that can hamper the stability of your vehicle.
- DO NOT exceed the legal speed limit or drive too fast for existing conditions. Always reduce speed when poor driving conditions exist. High speed increases the influence of any other condition affecting stability and increases the possibility of loss of control.
- Keep to the correct side of the road center line when meeting oncoming vehicle.
- All traffic signs, including manual controls at intersections, should be obeyed promptly. SLOW DOWN at traffic signs near schools and CAUTION signs at rail road crossings.
- When intending to turn, signal at least 100 feet (30.5 meters) before reaching the turning. Be close to the

RULES OF THE ROAD

center line (unless local rules require other-wise), slow down and then turn carefully.

- Never jump a traffic light. When a change is imminent from GO to STOP (or vice versa) at intersections, slow down and wait for the light to change to green. Never run through a yellow or red traffic light.
- DO NOT leave the curb or parking area without signaling. Be sure your way is clear to enter moving traffic. A moving line of traffic always has the right-of-way.



- When parking the motorcycle, park on a firm and flat surface to prevent it from falling over.
- Protect your motorcycle against theft. After parking your motorcycle, ensure that the steering head is locked and then remove the ignition key.

RULES OF THE ROAD

SIDE VIEW MIRRORS



Your motorcycle is equipped with convex mirrors and have a curved surface. This type of mirror is designed to give a much wider view of the rear than a normal flat mirror. However, vehicles and other objects seen in this type of mirror will look smaller and farther away than when seen in a flat mirror.

Use care when judging the size or distance of vehicles / objects seen in these mirrors.

NOTE

To establish the relative distance of vehicles / objects behind your motorcycle through the mirrors, adjust each mirror in such a way, that a small portion of your shoulder is visible and a large portion behind your motorcycle is seen clearly with reference to your riding posture.

60 | Royal Enfield Himalayan

RUNNING IN PERIOD

The Himalayan Motorcycle is capable of consistent high speeds. However as with any new motorcycle, a "RUNNING-IN PERIOD" procedure is essential to help in proper "Bedding-In" of the various moving parts in your motorcycle and to achieve optimum performance subsequently.

- 1. During the first 2000 Kms of run, do not exceed the speed limits as shown in the table below.
- 2. Do not exceed maximum specified pay load.
- 3. Warm up the engine for a few minutes at idling speed to allow engine oil to lubricate all the moving parts in the engine before riding the motorcycle.
- $4. \quad A void full throttle operation and do not ride at constant \\$ throttle continuously. Vary the speed by 10% while riding.


- 5. Avoid sudden accelerations and racing starts.
- 6. Avoid prolonged full-throttle operation. Vary speed occasionally.

Motorcycle Gear Speed		501 - 2000 kms
1	15 KMPH	20 KMPH
2	25 KMPH	30 KMPH
3	30 KMPH	40 KMPH
4	45 KMPH	55 KMPH
5	60 KMPH	80 KMPH

1. ENGINE MALFUNCTION INDICATOR LAMP

A Malfunctioning Indicator Lamp (MIL) is provided in the small meter.

When both the Ignition & Engine kill switch is "ON" and after vehicle is started, the MIL will glow for few



In the event of any malfunction in the EFI System the MIL will glow continuously. It is recommended to take the motorcycle to a nearest Royal Enfield Authorized service station for a detailed inspection and correction of the EFI system.

2. ANTI-LOCK BRAKING SYSTEM (ABS)

Anti-Lock Braking System (ABS) will help prevent the brakes from locking the wheels, during sudden application of the brakes at high speeds. This will help the rider to have better traction and control over the motorcycle and prevent the motorcycle



from skidding which can cause a accident.

In the event of sudden and hard application of the brakes by the rider, the sensors in the braking system will signal the ABS moderator to momentarily and continuously reduce the hydraulic pressure and thereby prevent the brakes from locking the wheels while reducing the speed of the vehicle. This will help the rider to control the motorcycle.

An ABS indicator lamp is provided in the console (as shown in adjacent image) to warn the rider in the event of any malfunction of the ABS.

When the ignition and kill switch are switched "ON", the ABS sign light up and remain "ON" till the motorcycle attains a speed of 5 Kmph (3MPH) and switch "OFF". This indicates the ABS is working properly. In the event the lamp does not switch "OFF" and remains continuously "ON" at higher speeds, it is recommended not to drive the motorcycle and get the brake system inspected and corrected through a nearest authorized Royal Enfield Distributor. Failure to do so can result in a serious injuries and loss of life.

CAUTION (ABS)

ABS is a safety feature to help prevent locking of wheels during sudden application of brakes. It is by no means a substitute for good riding practices and anticipatory braking.

Please ride carefully and apply brakes cautiously, especially while cornering. ABS cannot estimate the "weight shifts" and momentum of the motorcycle while negotiating a corner and therefore prevent skidding due to loss of traction.

Please anticipate the stopping distance required for the speed of travel and apply brakes well in advance so as to bring the motorcycle to a safe stop.

Please apply both brakes to stop - front brake momentarily earlier, followed by rear brake, to have better traction and control of the motorcycle.

Always ensure that you ride well within the legal speed limits.

Failure to adhere to the above can cause an accident resulting in serious injuries and loss of life.

The control function causes a slight pulsing of the hand and foot brake levers.

DO'S & DON'TS : (ABS)

DO'S	DON'TS
 While starting the engine do check the ABS indicator comes "ON" and switches "OFF" when the vehicle speed exceeds 5 km/h (3.1 mph). Please check the brake fluid at "MAX" level in the front and 	■ DO NOT RELEASE the brake lever / pedal when pulsations are felt during hard application of the brakes in an emergency situation. The pulsations only indicate that the ABS is activated.
rear brake master cylinders and there is no leak in the brakes systems.	
Apply both the brakes simultaneously for better efficiency while braking.	DO NOT APPLY only the front OR rear brake as it can lead to inefficient braking.
In the event of the ABS indicator remaining continuously "ON" please take the motorcycle to a nearest authorized Royal Enfield service station to inspect the brakes system control of the vehicle.	
ABS switch need to activate only on vehicle static condition.	Don't try to activate switchable ABS on vehicle running condition.

STARTING

 Ensure Gear is in Neutral position and the Neutral lamp is glowing in the Instrument Cluster. To shift into neutral, move the motorcycle back and forth gently, while simultaneously shifting the gear. Depress Clutch Lever fully.



CAUTION

Do not attempt to shift gears when engine is "OFF" and rear wheel is stationary as it will cause damage to gear shift mechanism. Please move motorcycle back and forth while simultaneously shifting gears.

■ Switch "ON" Ignition and the Stop Switch to "RUN" Position.



Press starter button and hold till engine starts.



STARTING

CAUTION

In case engine does not start, do not keep starter button pressed continuously as it will drain the battery. Release button and restart after a few minutes to allow battery to recoup.

CAUTION

Never accelerate the engine immediately after a cold start. The engine should be allowed to run slowly for 15 to 30 seconds. This will allow the engine to warm up and let oil reach all surfaces needing lubrication. Failure to adhere in damage to the engine.


NOTE

- It is recommended to switch off the engine when the engine is in idling condition for long time.
- It is recommended not to accelerate by giving excessive throttle for more than 5 minutes when the engine is in idle condition, which may cause damage to the engine internal parts and exhaust system as well.

GEAR SHIFTING, RIDING & STOPPING

■ Warm up engine for 2 minutes - until idling is ■ Press clutch lever towards the hand grip. consistent.

GEAR SHIFT PATTERN 1—N—2—3—4—5



- Press gear pedal with toe to engage 1st gear.
- Gently open throttle and release clutch simultaneously. If clutch is released suddenly, the engine may stall and cause a jerky start.

CAUTION

The clutch must be fully disengaged before attempting a gear shift. Failure to fully disengage the clutch may cause a jerky start OR stalling the engine besides causing damage to transmission parts.

GEAR SHIFTING, RIDING & STOPPING

■ Lift gear lever with toe to engage 2nd and subsequent gears.



NOTE

Always start the engine with gear in neutral position.


Always move the motorcycle in first gear position only.

The motorcycle may begin to slow down and show lack of power while climbing steep hills. In that case, you should shift to a lower gear so that engine will be operating in normal power range which will prevent the motorcycle from losing momentum. The engine may be used for braking by shifting to a lower gear while riding down to steep hill.

PARKING

PARKING MOTORCYCLE ON SIDE STAND

- Select a firm, flat surface.
- Extend side stand. Tilt the motorcycle to the left, till it is supported firmly.



CAUTION

When Side stand is in "ON" position.

- a) Engine will start if vehicle is in neutral, but will cut-off (ignition and fuel) when gear is engaged.
- b) Engine will not start if gear is engaged already.

WARNING

- Ensure side stand is retracted fully before riding the motorcycle.
- Please exercise extreme care while parking and ensure it is parked firmly to avoid the motorcycle from falling

PARKING

over and causing injury to you or to others and damage to the motorcycle parts.

■ Do not ride motorcycle with the side stand extended. Doing so can cause the side stand to touch the ground while cornering and result in instability & loss of control on the motorcycle leading to a potential accident result in serious injury to both sides and other road users besides causing severe damage to the motorcycle.

NOTE

The Side stand is only designed for the weight of the motorcycle. Do not sit on the motorcycle when it is resting on the side stand. The side stand or frame may become damaged and the motorcycle may fall over.

ENVIRONMENT CARE

BE AN ENVIRONMENTALLY CONSCIOUS RIDER

You've ridden through some beautiful places on your Royal Enfield. Won't you like to keep them that way? Here are some tips to help you keep those places unspoilt so that others can enjoy them too:

ENGINE OIL

While your liquid waste like engine oil, gasoline, coolant and other cleaning solvents need to be regularly replaced, what happens to them? Make sure they are not dumped in the soil, down the sewers, drains, lakes or rivers around you. The simplest way to do it is to have them drained into a container which you can hand over to your local recycling

agent or at your nearest Royal Enfield service centre. They will follow the guidelines laid down by the local authorities to get rid of it.

BATTERY

If your Royal Enfield's battery needs to be replaced, hand it over to an authorised recycling agent or Royal Enfield service centre. They will follow the guidelines laid down by the local authorities to get rid of it. This will ensure the dangerous substances from which the battery has been manufactured do not pollute the environment.

ENVIRONMENT CARE

TYRE(S)/PLASTIC/ELECTRICAL/ELECTRONIC PARTS/OIL FILTER

If your Royal Enfield's tyre(s)/plastic/electrical/electronic part(s)/oil filter need to be replaced make sure you hand them over to an authorised recycling agent or a Royal Enfield service centre. They will follow the local authority's guidelines to get rid of them in an environmentally friendly manner.

CLEANING YOUR ROYAL ENFIELD

Avoid aerosol sprays; instead, use a biodegradable detergent or dry wash to wash your Royal Enfield. Also, be cautious while discarding the cleaning solvents. Hand them over to an authorised recycling agent or a Royal Enfield service centre. They will follow the local authority's guidelines to get rid of them in an environmentally friendly

This note does not constitute legal advice; please contact your local authorities or your nearest Royal Enfield Service Centre for further guidance.

The Periodical maintenance schedule detailed below is based upon average riding conditions and indicates the intervals at which regular inspections, adjustments, replacements and lubrications must be carried out to help maintain your Himalayan motorcycle meticulously. If in case the motorcycle is used frequently in very dusty environment / severe climatic conditions / Poor Roads / stagnant water etc., the maintenance will need to be done earlier as may be required.

Contact a nearest Royal Enfield Authorised Dealer / Service Centre to carry out the periodical maintenance and for any expert advice.

SI. No.	DESCRIPTION	PERIODICAL MAINTENANCE											
	Kms (x 1000)	0.5	5	10	15	20	25	30	35	40	45	50	
	Miles (x 1000)	0.3	3	6	9	12	15	18	21	25	28	31	
	Months	1.5	6	12	18	24	30	36	42	48	54	60	
1	Engine Oil (Level check / Replace)	R	l	R	I	R	1	R	ı	R	ı	R	
Ľ	Engine on (Level check) Replace)		Che	eck lev	el at ev	very 10	00 Kn	ns or e	arlier a	s requ	ired		
2	Engine Oil Filter Element	R		R		R		R		R		R	
3	Engine oil strainer on crankcase LH	С		С		С		С		С		С	
4	Inlet / Exhaust Tappet setting	I&A	I&A	I&A	I&A	I&A	I&A	I&A	I&A	I&A	I&A	I&A	
5	Rubber hose, Inlet manifold *	ı	ı	ı	ı	ı	1	ı	ı	R	ı	1	

SI. No.	DESCRIPTION				PERI	ODICA	LMAIN	NTENA	NCE			
	Kms (x 1000)	0.5	5	10	15	20	25	30	35	40	45	50
	Miles (x 1000)	0.3	3	6	9	12	15	18	21	25	28	31
	Months	1.5	6	12	18	24	30	36	42	48	54	60
6	Oil cooler inlet & outlet pipes *	1	ı	ı	1	1	1	ı	1	I	1	1
7	Spark plug	C&A	C&A	C&A	R	C&A	C&A	R	C&A	C&A	R	C&A
8	HT leads for crack	ı	ı	I	J	I	I	ı	I	ı	I	ı
9	Fuel Hose & Clip	ı	ı	ı	J	ı	ı	ı	ı	R	ı	ı
10	Fuel Pump (under tank) Mounting		C	heck f	or scre	w tigh	tness ir	n all se	rvices			
		С	С	R	С	R	С	R	С	R	С	R
11	Air filter element		Clean/	Repla	e mor	e frequ	uently i	if moto	rcycle	alway:	s used	
	in dusty / off Road conditions.											
12	Accelerator Cable	I&A	I&A	I&A	I&A	I/A/R	I/A/R	I/A/R	I/A/R	I/A/R	I/A/R	I/A/R

SI. No.	DESCRIPTION	PERIODICAL MAINTENANCE										
	Kms (x 1000)	0.5	5	10	15	20	25	30	35	40	45	50
	Miles (x 1000)	0.3	3	6	9	12	15	18	21	25	28	31
	Months	1.5	6	12	18	24	30	36	42	48	54	60
13	Rubber Hose, Air fitler to Throttle body	ı	ı	ı	ı	ı	ı	ı	ı	R	ı	
14	PAV pipes & Hose clip	I	1	1	1	1	1	1	ı	R	1	ı
15	Evaporative Emission Equipment rubber hoses*	ı	I	ı	ı	ı	ı	ı	ı	R	ı	ı
16	Throttle body should be removed from the vehicle and clea with a dry Microfibre cloth, Usage of throttle body cleaners similar solvent or alcohol based liquids for cleaning is strict prohibited. Throttle body cleaning every 10000 kms / 12 N or earlier as required.		ners or rictly	any								
17	Clutch Cable		I&A	I&A	I&A	I/A/R						

SI. No.	DESCRIPTION		PERIODICAL MAINTENANCE									
	Kms (x 1000)	0.5	5	10	15	20	25	30	35	40	45	50
	Miles (x 1000)	0.3	3	6	9	12	15	18	21	25	28	31
	Months	1.5	6	12	18	24	30	36	42	48	54	60
18	Clutch free play			Adjust	every	1000	Kms or	earlier	as req	uired		
19	Clutch no slippage	1 1 1 1 1 1 1 1 1 1				ı						
20	Steering head bearings #	1&A	Ins	pect, a	djust 8 req		cate fo Replac				earlie	r as
21	Front Fork oil / leak	ı	ı	ı	ı	R	ı	ı	ı	R	ı	ı
22	Rear Wheel Drive Chain #	I&A	I&A Clean, Lubricate & Adjust every 1000 Kms or earlier as require				quired					
23	Battery terminals (apply petroleum jelly)	С	С	С	С	С	С	С	С	С	С	С
24	Earth wire eyelet Tightness			I		I		J		I		I
25	Hydraulic Brake Fluid - Front & Rear #	Ī	Ī	Ī	Ī	R	Ī	Ī	Ī	R	ı	Ī

SI. No.	DESCRIPTION	SCRIPTION PERIODICAL MAINTENANCE										
	Kms (x 1000)	0.5	5	10	15	20	25	30	35	40	45	50
	Miles (x 1000)	0.3	3	6	9	12	15	18	21	25	28	31
	Months	1.5	6	12	18	24	30	36	42	48	54	60
26	Hydraulic brake hose & Washers - Front & Rear #	ı	ı	1	1	1	ı	ı	ı	ı	1	1
27	Brake Pads - Front & Rear #	ı	ı	ı	1	ı	ı	ı	ı	ı	ı	1
28	Tyre wear pattern (Front & Rear) # (1)	I	ı	ı	1	1	I	ı	ı	ı	1	l
29	Spokes tightness / Wheel rim run out front & rear #	ı	l	I	ı	ı	ı	ı	ı	ı	ı	ı
30	Front & Rear wheel bearings for play #	I	ı	ı	1	1	I&R	ı	ı	ı	1	I&R
31	Swingarm Pivot Bearings #	I	Inspect & If required lubricate for every 5000 km or earlier as required. Replace if necessary					lier				

SI.												
No.	DESCRIPTION	PERIODICAL MAINTENANCE										
	Kms (x 1000)	0.5	5	10	15	20	25	30	35	40	45	50
	Miles (x 1000)	0.3	3	6	9	12	15	18	21	25	28	31
	Months	1.5	6	12	18	24	30	36	42	48	54	60
32	Rear Suspension Linkages #	I Inspect & If required lubricate for every 5000 km or earlier as required. Replace if necessary				iier						
33	Rear Brake Pedal Pivot	L	L	L	L	L	L	L	L	L	L	L
34	Rear Brake Pedal free play			Adjust	every	1000	Kms or	earlie	r as red	quired		
35	Rear wheel cush rubbers #	ı	ı	ı	I	I&R	I&R	I&R	I&R	I&R	I&R	I&R
36	All Mounting Fasteners in vehicle for tightness #	I&T	I&T	I&T	I&T	I&T	I&T	I&T	I&T	I&T	I&T	I&T
37	Hand levers, Center stand, Side stand, Rider & Pillion foot rest pivots & Gear shift levers #	Lubricate every 1000 Kms or earlier as required										
38	Cam Chain / Chain Pads / Auto chain Tensioner	er I I I I I I I I I I				ı	I&R					

SI. No.	DESCRIPTION		PERIODICAL MAINTENANCE									
	Kms (x 1000)	0.5	5	10	15	20	25	30	35	40	45	50
	Miles (x 1000)	0.3	3	6	9	12	15	18	21	25	28	31
	Months	1.5	6	12	18	24	30	36	42	48	54	60
39	Starter motor & Starter relay connections	ı	ı	ı	ı	I	ı	ı	ı	ı	ı	1
40	Side stand switch operation	ı	ı	J	ı	ı	I	ı	ı	ı	ı	I

 $\begin{array}{lll} A: A djust & C: Clean & I: Inspect (Clean, Adjust, Lubricate or Replace if necessary) \\ T: Re-tighten (2) & L: Lubricate & R: Replace \end{array}$

 $\label{thm:continuity} \textit{\#}\, \mathsf{Service}\, \mathsf{more}\, \mathsf{frequently}\, \mathsf{when}\, \mathsf{riding}\, \mathsf{in}\, \mathsf{rain}\, \mathsf{or}\, \mathsf{at}\, \mathsf{full}\, \mathsf{throttle}.$


(1) Tyre to be replaced if the tyre wear identification mark reached (2) To be done at authorised Royal Enfield Dealer / Service Center For maintenance after 50,000 Kms., please repeat same frequency specified above, in consultation with a Royal Enfield Authorised Dealer / Service Centre.

^{*} Refer Service Manual. # Service more frequently when ridden in unusually wet or dusty areas.

TOOLS KIT

The tool kit is strapped underneath the Pillion seat.

S.No.	Tool Description	Purpose	Qty.
1	A ll en Key 4 mm	To remove side panels LH & RH	1
2	Allen Key 6 mm	To Loosen / tighten pinch bolt on fork end	1
3	Tool Spark Plug	To Loosen / tighten Spark plug	1
4	Screw Driver	To Loosen / tighten screws of housing	1
5	Extension Tube	Additional leverage for loosening tightening wheel axle nuts	1
6	Combination Spanner Open end 17 * 13 mm	To Loosen / tighten hex nuts	1
7	Combination Ring Spanner 24 * 14 mm	To Loosen / tighten wheel axle nuts	1
8	D.E. Spanner 10 * 12 mm	To Loosen / tighten hex nuts	1
9	Tool wallet	For storing tools	1



Royal Enfield Himalayan | 81

The following simple maintenance activities will help in maintaining your motorcycle. However if you are in experienced or feel it is best done by an experienced person, we recommend you to get in touch with a Royal Enfield Authorised Dealer / Service Centre.

HAND LEVER PIVOTS

Wipe the area free of dirt / grease.

Apply a few drops of oil on the pivots.



SIDE STAND PIVOTS

Apply a few drops of oil on the pivots after cleaning the area of dirt.




PERIODICAL MAINTENANCE

■ Lubricate the center stand pivot periodically for smoother operation of center stand.



DRIVE CHAIN

Clean the drive chain carefully. Apply chain lubricant while simultaneously rotating the rear wheel. Wipe off the excess lubricant.



OIL LEVEL INSPECTION

- Place motorcycle on its center stand on a firm surface.
- Warm up engine for a few minutes & switch off before checking oil level.



- The level is correct if the oil level is in the middle of the oil level window.
- Top up only with recommended Engine oil.

CAUTION

Using Non Recommended / In-correct oils, can cause serious damage to the moving parts, affect performance of the motorcycle AND void the warranty.

SPARK PLUG

CLEANING AND ADJUSTING PLUG GAP

- Remove the spark plug cap from the spark plug.
- Remove spark plug using the plug spanner and tommy bar.
- Clean the insulator tip and electrodes of the plug carefully.
- Clean & adjust electrode gap every 500 km if required and replace every 15,000 kms.
- Refit the spark plug on the cylinder head.
- Refit the spark plug cap on the spark plug.
- Make sure the spark plug, spark plug cap and HT cable are proper fitment.

BRAKE FLUID

- Check fluid level is between "MIN & MAX".
- Top up with DOT 4, if required.
- Do not overfill.
- DO NOT mix DOT 4 with other brake fluids.







CAUTION

Brake fluid is highly corrosive and can cause damage to painted parts. Please ensure brake fluid does not spill on any part of the motorcycle. In the event of a spill, please clean the area immediately with a soft cloth (preferably a wet cloth) to avoid damage.

INSPECTION OF TYRES AND RIMS

- Periodically inspect :
 - Rims for spokes breakage wheel rim and run-out.
 - Tyres for proper seating of the beading on the rims.
- Check and remove stone, splinters, nails or other sharp particles embedded in the tyre.

- Replace tyres if
- Side wall cracks, cuts or damages, uneven lugs wear etc.
- Tyre lugs work out upto the "wear indicator" symbol on the side wall.



Use only recommended tyres & tubes, inflated to correct air pressure.

	Front	Rear
Solo	1.75 kg/cm ² (25 PSI)	2.25 kg/cm ² (32 PSI)
With Pillion	1.89 kg/cm ² (27 PSI)	2.39 kg/cm ² (34 PSI)



Dismantling and reassembly of the wheel should be done ONLY by an experienced technician.

Failure to do so may cause loss of control on the motorcycle, leading to a potential accident, resulting in serious injury to both rider and other road users, besides causing severe damage to the motorcycle.

FRONT WHEEL REMOVAL

- Support front end of engine suitably such that the front wheel is off the ground.
- Loosen pinch bolt on right fork end with 6 mm Allen key.
- Hold spindle on right side and remove spindle nut and washer from left side.





■ Support wheel and pull out spindle from right side.



■ Remove the wheel along with RH side spacer & Disc side spacer OR



(Follow below procedure if vehicle have a wheel speed sensor assembly).

Remove wheel along with wheel speed sensor and spacer.

CAUTION

Do not press the brake lever when wheel is removed as this will result in the brake pads coming out too far from the brake caliper.


■ Place a suitable spacer of 4 mm thickness, between the brake pads to avoid accidental compression of the brake lever.

FRONT WHEEL REASSEMBLY

- Remove the spacer placed between the brake pads.
- Locate wheel speed sensor lugs on the hub slot carefully.
- Position the wheel along with RH side Spacer & Disc side spacer on left side between the front fork legs, ensuring the brake disc is located between the brake pads.

OR





■ Ensure the position of RH side Spacer & Disc





side spacer aligned properly.

OF

(Follow below procedure if vehicle have a wheel speed sensor assembly).

Position wheel speed sensor such that it is parallel to ground.

- Holds spindle on right side, locate washer and nut on spindle on left side and tighten firmly.
- Tighten pinch bolt on right fork end.
- Rotate wheel and check for smooth rotation.
- Press brake lever and check front brake for efficiency.

REAR WHEEL REMOVAL

■ Ensure the motorcycle is on a firm, flat surface and the rear wheel is off the ground.



 Gently remove the brake hose along with its rubber grommets from the locating clips on the swing arm.



■ Loosen rear axle nut on the right side and remove along with washer.



■ Pull out the wheel axle from the left side, taking care not to drop the wheel spacers.



- Remove the brake caliper assembly from the slot in the swing arm along with ABS wheel speed sensor and support it suitably to avoid damage to the brake hose and ABS wheel speed sensor.
- Slide out the rear wheel from the swing arm, taking care not to drop the spacers on the wheel hub.

CAUTION

Do not press the brake pedal when wheel is removed as this will result in the brake pads coming out too far from the brake caliper.

* Place a suitable spacer of 4 mm thickness, between the brake pads to avoid pads compression in the event the brake pedal is pressed accidentally.

REAR WHEEL REASSEMBLY

- Ensure the cush rubbers are in place in the wheel hub.
- Insert the wheel assembly between the swing arms and position the cush rubbers on the rear sprocket lugs correctly.
- Remove the spacer between the brake pads and locate the caliper such that the brake disc is between the brake pads.





- Locate the caliper bracket slot on the lug in the swing arm.
- Position the respective spacers on the left and right side of the wheel hub.
- Ensure the axle mounting hole in the swing arm, wheel hub and caliper bracket are aligned.
- Insert the wheel axle from the left side of the swing arm and gently tap it in.

CAUTION

- Do not force the spindle through as it will cause damage to the threaded end.
- 0
- Ensure correct chain tension and rear wheel alignment with front wheel by adjusting the adjusters on both left and right side of swing arm.



- Assemble washer and wheel axle nut on right side and tighten to correct torque.
- Fix the brake hose pipe in swing arm clips properly.



CAUTION

- Please ensure the brake hose is correctly positioned on the clips, without any twist, sharp kinks or damage as it will seriously affect the performance of the rear brake
- Check rear brake for effectiveness and correct functioning before using the motorcycle.

DRIVE CHAIN TENSION (FREE PLAY 20-30mm)

- Measure the drive chain free play on the top run of the chain.
- The recommended free play is 20 to 30 mm.

To adjust the chain tension and free play:

- Loosen rear wheel spindle
- Loosen lock nuts of the chain adjuster on both ends of the swing arm.





- Tighten/loosen the adjuster nut on left swing arm end, to reduce / increase chain tension.
- Ensure the ground is level & firm and place the motorcycle in its center stand.
- Rotate wheel slowly and check chain free play at the top run to be between 20 - 30 mm.



 $Please follow instructions \, as \, per \, periodical \, maintenance.$

- Tighten / loosen adjuster nut on right side to align the front and rear wheels and also to align the reference marks on both left and right side of the swing arm.
- Tighten the lock nuts against the adjuster nuts, taking care not to disturb the adjuster nut settings.
- Tighten rear wheel spindle nut to a specified torque.





WARNING

Chain slackness beyond 30mm will lead to chain slippage.

Maintain drive chain slackness within the specified limits at every 1000 kms interval.

Please Check the front and rear wheels are correctly aligned, after the chain adjustment.

If the Engine / Rear sprocket are worn, replace the Engine / Rear sprocket & Rear chain as a kit.

ADJUSTMENTS - CLUTCH LEVER FREE PLAY

Clutch Lever (free play 2 - 3 mm)

- Loosen the cable outer lock nut (A).
- Turn the Nut (B) Clockwise to reduce the play or Anticlockwise to increase the free play.
- Check free play 2 to 3 mm at Clutch lever pivot on handle bar end.
- Tighten lock nut (A) after adjustment is done.





ADJUSTMENT - REAR BRAKE PEDAL FREE PLAY

Rear brake pedal free play 7 to 11 mm.

 Loosen the lock nut in master cylinder push rod assembly.




- Rotate the master cylinder push rod anti clockwise to reduce the rear brake pedal free play.
- Rotate the master cylinder push rod clockwise to increase the rear brake pedal free play.
- After adjustment tighten the lock nut in master Cylinder push rod assembly.

BRAKE PAD WEAR

■ Brake pad wear depends upon the severity of usage, the type of riding and road condition.



Check the wear indicator mark on each pad. If either pad is worn to the wear indicator mark. Replace both pads as set. Visit royal enfield dealer for this service.



Check the wear indicator mark on each pad. If either pad is worn to the wear indicator mark. Replace both pads as set. Visit royal enfield dealer for this service.

BATTERY & MAINTENANCE

- The Motorcycle is provided with 12V - 8 AH MF battery.
- The battery must be periodically checked for corrosion free terminals.



REMOVAL OF BATTERY FROM THE MOTORCYCLE

■ Remove the side panel on the right sight by unscrewing the hex socket button head screws.



- Ensure motorcycle is parked on its center stand, in a well ventilated area.
- Ensure the ignition switch and engine stop switch are in "OFF" position.
- Disconnect the Harness connectors around the battery located area.

- Unlock (turn the key clockwise) and remove the pillion
- Remove front seat.
- Remove the Battery carrier bracket by loosening the hex bolt.
- Disconnect both the Battery terminals wires (negative first and positive next respectively).



■ Take out the battery.





WARNING

Always disconnect the Black negative (-) battery cable first and then the Red positive (+) cable while removing the battery connections.

REASSEMBLY OF BATTERY ON MOTORCYCLE

- Position the battery in the battery carrier such that the terminals are facing inside.
- Ensure ignition switch is in "OFF" condition.
- Connect the red wire to the positive terminal of the battery first.
- Next, connect the black wire to the negative terminal of the battery.
- Smear the terminals with petroleum jelly. (Do not use grease in the battery terminals).

- Place the terminal boot / cap properly.
- Refit the battery bracket.
- Reconnect the harness connector to the respective couplers on the battery located area.
- Refit the right side panel.
- Reassemble rider seat & Pillion seat.

NOTE

- Clean the wire terminals free of corrosion and keep the terminals coated with petroleum jelly.
- It is not necessary to check the battery electrolyte level or add distilled water as the battery is a maintenance free (Sealed type).

 Your Battery is a maintenance free type and can be permanently damaged if the cap strip is removed.

CAUTION

Keep the +ve and -ve cables firmly conneted to the respective battery terminals. Failure to do so may result in damage to the motorcycle electrical system.



Always disconnect the negative (-) battery cable first and then the positive (+) cable while removing the battery connections. If the positive (+ve) battery cable should contact terminal with the negative (-ve) cable installed, the resulting sparks may cause a battery explosion which could result in serious injury.

WARNING

Battery terminals and internals contain lead and lead components, known to cause cancer and birth defects or other reproductive harm. Always wear approved protective face shield, rubberized gloves and protective clothing when working with batteries. KEEP BATTERIES AND ACID OUT OF REACH OF CHILDREN.

NOTE

Usage of frequency for motorcycle is very important for battery to be in good performance condition. If the motorcycle is being used very rarely or sparingly and the terminals are not disconnected the battery is bound to lose its charge and result in a dead battery.

CHANGING ELECTRICAL COMPONENTS

HEADLAMP BULB DISMANTLING

- Remove the 2 screws holding the head lamp rim to the housing.
- Gently pull out the head lamp rim along with reflector assembly.
- Disconnect head lamp coupler.
- Remove the protective rubber cap over the bulb.







- Gently press the bulb holding clip and release it from the slot in the reflector.
- Remove the bulb from the reflector.

NOTE

Never touch the bulb with your fingers. Finger prints will etch the glass and decrease bulb life.

Always hold the bulb with clean dry cloth during handling.

Don't disturb the vent cap provided in the inner body mould.







HEAD LAMP BULB REPLACEMENT

■ Locate the 3 lugs in the bulb correctly in the reflector.



 Locate the bulb holding clip over the bulb and lock it in the slot in the reflector.



 Put the protective rubber cap over the bulb correctly such that the vent pipe is facing downwards.



 Connect head lamp coupler on the bulb terminals correctly.



Locate the head lamp rim in the housing correctly such that it locks in place and the 2 mounting holes of the rim are aligned with the holes in the housing.



Assemble the 2 screws and tighten firmly.

TAIL LAMP & LICENSE PLATE ILLUMINATOR

The tail lamp & license plate illuminator has a LED lighting system. In the event of failure, the entire tail lamp & license plate illuminator assembly should be replaced.

Contact an Authorised Royal Enfield Dealer / Service Centre to replace the same.



TRAFFICATOR BULB REPLACEMENT

- Remove the screw from the trafficator housing back side.
- Remove outer lens.
- Remove the fused bulb by pushing and turning in anticlockwise direction.



- pins in the bulb, match with slots in the holder. ■ Push the bulb and turn clockwise direction to lock the
- bulb in the holder.
- Refit the trafficator cover with reflector and tighten the screw.

Do not over tighten the screw. Make sure the Ignition switch is in "OFF" position when replacing the Bulbs, Fuses and Electrical parts.


FUSE

- Remove the RH side panel.
- Replace the required fuse with the spare fuse available in the fuse carrier.
- The blade fuses are located in the carrier.

NOTE


Please ensure to replace a spare fuse in the holder at the earliest opportunity.

RELAY STARTER - FUSE BOX



FUSE & CARRIER

- The fuse carrier is located under the rider seat
- Remove pillion seat & rider seat.
- Open the fuse carrier lid & replace fuse as indicated inside the lid.
- Replace the required fuse with the spare fuse available in the fuse carrier.



NOTE

- F2 Device Bt + Fuse 10A EMS ECU, Instrument Cluster, Tripper.
- F3 Ignition Fuse (EFI) 15A Relay Coil, EMS ECU, Ignition Coil, Fuel pump, Injector, O2 Sensor, E purge and Diagnostic tool.
- F4 Signalling Fuse 15A Instrument Cluster, Tripper, Gear Position Sensor, Flasher, Brake Switch and Horn.
- F6 Lighting Fuse 15A Headlamp Low & High Beam, Front Position Lamp, Rear Position Lamp & License Plate Illuminator. Please ensure to replace a spare fuse in the holder at the earliest opportunity.

BLADE FUSE USAGE LIST

ID No.	Function	Rating
F1	CHARGING FUSE	25A
F2	DEVICE Bt+ FUSE	10A
F3	IGNITION FUSE (EFI)	15A
F4	SIGNALLING FUSE	15A
F5	SPARE FUSE	5A
F6	LIGHTING FUSE	15A

ID No.	Function	Rating
F7	ABS MAIN 1	15A
F8	ABS MAIN 2	10A
F9	ABS IGNITION	5A
SF1	SPARE FUSE	10A
SF2	SPARE FUSE	15A
SF3	SPARE FUSE	25A

WARNING

Please get the electrical system of your Motorcycle checked thoroughly and get the faults corrected immediately after experiencing any fuse failure. Not doing this can result in to repeated fuse failures.

Usage of fuses other than specified rating will damage the complete electrical system.

MINOR MAINTENANCE TIPS

WINDSHIELD CLEANING

Wipe the windshield with a soft cloth. Do not wipe vigorously as it will cause scratches on the windshield.

Use a mild detergent and lukewarm water to remove any hard coating, insect hits etc. from the windshield.



Rinse well with water and use a soft dry and lint free cloth to wipe off the water.

CAUTION

Use of any hard cleaning substances such as stain removers, water repellent compounds, petroleum

products, solvents and alcohol based material will seriously affect the windshield transparency.

Scratches, cloudiness, cuts and abrasions on the windshield cannot be polished or removed. The windshield must only be replaced if damaged.

WARNING

Never attempt to clean the windshield while riding. Failure to do so may cause loss of control on the motorcycle, leading to a potential accident, resulting in serious injury to both rider and other road users, besides causing severe damage to the motorcycle.

LONG TRIP PRECAUTIONS

CHECKS PRIOR TO THE COMMENCEMENT OF LONG JOURNEY

- Service the motorcycle at a Royal Enfield Authorised Dealer / Service Centre.
- Ensure sufficient quantity of petrol in the fuel tank for the journey planned.
- Check and correct tyre pressure if necessary.

CHECKS AFTER EVERY 1500 KMS OF RUN

- Any loose fasteners.
- Condition of the tyres.
- Correct oil level in engine.


- Working of all lights and horn.
- Proper drive chain tension.

ITEMS TO BE CARRIED

- Tool kit.
- Bulbs for Headlight, Trafficator light, Fuse.
- Accelerator, Clutch cables.
- Rear chain master link lock assembly.
- Insulation tape.
- Spark plug, Spark plug cap.

SHOCK ABSORBER

SPRING PRELOAD & SHOCK ABSORBER SETTINGS



INCREASING THE PRELOAD

 To increase spring preload, turn preload adjuster in the clockwise direction.

REDUCING THE PRELOAD

■ To decrease the spring preload, turn preload adjuster in the anti-clockwise direction.

CAUTION

It is recommended to visit Authorised Dealer for adjusting spring preload and shock absorber settings.

OFF ROADING

AFTER OFF ROADING

It is recommended to check the following after off roading:

TYRE PRESSURE

- Tyre pressure needs to be optimal for effective riding on surfaced roads.
- Always check the tyre pressures are correct.

- Riding on dirty & muddy roads brakes may not be effective immediately because of dirts & moisture on the disc pads.
- Apply the brakes in good time until the brakes have been cleaned.

RIMS

■ It is recommended to check the rims & wheels for damage after off roading.

SPRING PRELOAD & SHOCK ABSORBER **SETTINGS**

- The off road settings of spring & shock absorber settings will impair the motorcycle's handling characteristics on surfaced roads.
- Remember to correct the spring & shock absorber settings before returning to surfaced roads.

AIR FILTER ELEMENT

- Cleaning of air filter element is recommended for effective utilisation of air filter element in returning to
- Check for any damages or clog in air filter and replace if required.

PRECAUTIONS

- Wash motorcycle when the engine is cold.
- Cover the silencer, tail pipe, horn, Control switches, Instrument cluster & Tripper with suitable plastic bags and tie it firmly to prevent water entry.
- Remove ignition key and seal key hole using adhesive tape.
- Brush engine area with a solvent to remove dirt or grease.
- Use low pressure jet of water to clean.
- DO NOT spray water directly on the steering stem area as it will damage the bearings and course the handle bar movement to become sticky.

- Never spray water with great force on head lamp, speedometer, flasher lights, front and rear wheel hubs, electrical connections and wires, control cables, cables, sparkplug, battery, ABS ECU, EMS ECU, side mirrors, steering stemetc.
- Do not apply any corrosive solvent on painted surfaces or rubber parts.
- Use luke warm water and mild detergent on the painted components to remove dirt, etc.
- Rinse motorcycle thoroughly with plain water to remove the detergent.
- If possible, use compressed air and blow off water particles from the hard to reach areas of the motorcycle, electrical connections etc.

- No direct jet at the edges of decal, electrical parts, coupler joints, silencer tail pipe, radiator lubrication points like steering cone kit, brake pedal, wheel bearings, chain, brake cam & swing arm bushes to be washed in spray mode only (not in jet mode).
- Once the motorcycle has been ridden in salty conditions or near coastal areas it is recommended to wash your motorcycle with cold water. Please do not use warm water for washing as it may damage the motorcycle due to chemical reaction with the salt. After washing process once the motorcycle is completely dry it is recommended to apply anti corrosion spray on all the metal and chrome plated areas to protect the parts from corrosion.
- It is recommended not to apply the anti-corrosion spray on the brake discs.

AFTER WASHING

- Ensure, the motorcycle is thoroughly dry by wiping with a clean soft absorbent cloth or chamois leather.
- Remove all plastic bags and adhesive tapes.
- Lubricate control cables, pivot and rear chain with lube oil.
- Polish the painted (except Stone Black Colour / Matt paint finish) and plated surfaces using polishing wax.
- Start engine and allow to run at idling speed for a few minutes to warm up engine.
- Drive the motorcycle slowly, applying both brakes intermittently to dry up the water in the brake shoes.



NOTE

High pressure water Jet should not directly Shown on the above mentioned Locations.

Location		Do's	Don'ts		
Oil Cooler Fins Damage	Use protector to cover the fins Location	7	Don't use High pressure water jet on Oil Cooler	×	
Instrument Cluster	Wipe Head lamp glass with Cotton Cloth		Don'tuse High pressure Water on Head lamp Front & back	×	

NOTE

High pressure water Jet should not directly Shown on the above mentioned Locations.

Location		Note		
Stickers on Front Mudguard, Rear Mudguard & Side Panel	High pressure water Jet should not directly Shown on these Locations.	THE REPORT OF	STOLENS	Hitra LAVA

116 | Royal Enfield Himalayan

STORAGE PRECAUTIONS

In case your Motorcycle is not going to be used for a month or more, the following precautions should be taken.

- Get the motorcycle serviced through a Royal Enfield Authorised Dealer / Service Centre.
- Drain fuel tank and fuel line.
- Spray engine oil inside the fuel tank to prevent rusting.
- Remove spark plug. Pour in about 25ml of clean engine oil through spark plug hole. Close the hole and crank engine several times and refit spark plug.
- Clean rear chain thoroughly and apply a chain lube.

- Remove battery from the motorcycle. Clean the terminals free of corrosion and apply petroleum jelly to terminals.
- Store the battery in a cool, dry and well ventilated place.
- Cover the silencer with plastic bags to prevent moisture entry. Set the motorcycle on its center stand.
- Apply anti rust solutions on all plated parts. Take care not to apply this solution on rubber or painted parts.
- Store motorcycle in a clean covered area free of moisture and dust.

STORAGE PRECAUTIONS

- For re-use after storage, it is preferable to get the motorcycle prepared through a Royal Enfield Authorised Dealer / Service Centre to ensure the motorcycle is restored to its peak operating conditions.
- If the motorcycle is not used for a month or longer, It is advised to disconnect battery terminals and remove the battery. Before refitting the battery in the motorcycle, check the battery voltage is within specification, if not, recharge it from authorized service workshop / battery dealer.

WIRING DIAGRAM

Disclaimer: It is recommended that the wiring circuit repair and any other electrical rework should be performed only by an authorized Royal Enfield service centre, failure to adhere this may cause damage to electrical systems and render the warranty of the products as void.



We have listed below a few basic checks in case your motorcycle is not functioning. If in case the problem is not rectified after these checks, it is necessary to get the motorcycle checked by a Royal Enfield Authorised Dealer / Service Centre to rectify the problem and to ensure trouble free performance.

Symptom	Observations	Check for / Remedy	
	In Ignition / Engine stop switch is in 'OFF' position	Switch 'ON' Ignition / Engine stop switch.	
	2. Very low / No fuel in the fuel tank.	Fill fuel.	
Engine Does	3. Lights / horn very dim (Horn Poor / Low Sound)	Weak / Discharged battery, Contact Authorised Service Centre.	
not start	4. Electricals not working	Battery completely dead. Replace battery. Fuse Blown. Replace appropriate fuse. Note: If fuse blows again, contact Authorised Service Centre.	

Symptom	Observations	Check for / Remedy	
Engine Does	5. Engine Cranking but not starting	Spark plug Cap / wire disconnected. Reconnect Check if SIDE STAND is ON / SIDE STAND SWITCH MALFUNCTION.	
not start		Check if gear is engaged and the side stand is down.	
		If the ambient Temperature is low use Manual Bi-starter.	
Engine Starts BUT shuts off	Engine shuts off as soon as throttle is	Idling RPM set too low / setting disturbed. Contact Authorised Service Centre for resetting the Idling RPM.	
immediately	closed.	Check if the MIL Lamp is glowing; If yes, Contact Authorised Service Centre.	

Symptom	Observations	Check for / Remedy
Engine Misfires &	Typically happens after a Refill / Adulterated / Water in Fuel.	Drain out entire fuel and Refill with fresh fuel from a reputed filling station.
Runs Erratically / Stops	Motorcycle driven in Low gear / High RPM / Crowded places for long time.	Excessive Engine temperature. Switch 'OFF' Engine and allow to cool down.
		Check if the MIL Lamp is glowing; If yes, Contact Authorized Service Centre.

Symptom	Observations	Check for / Remedy	
	Engine RPM raises disproportionately to motorcycle speed.	Clutch is Slipping. Check for sticky clutch / clutch not having any free play.	
Poor Pickup	Rear Chain excessively loose causing chain to slip on Sprocket.	Adjust Rear chain to correct tension.	
		Check if the MIL Lamp is glowing; If yes, Contact Authorized Service Centre.	
ABS (Anti lock Braking system)	ABS lamp continuously "ON".	Take the vehicle to service centre for diagnosis.	

WARRANTY TERMS & CONDITIONS

Royal Enfield Motorcycles are manufactured by following best Quality practices in respect of the material and workmanship.

Royal Enfield (RE) warrants its motorcycle to be free from manufacturing and material defect under normal use subject to following conditions.

- 1. Warranty shall be in force until the expiry of a period of 36 months from the first date of sale to the first customer and to any subsequent owners for the balance of the remaining period, until expiry of 36 months from the date of first sale / registration of the motorcycle.
- 2. In order to effect Warranty, it is a prerequisite that the maintenance schedule prescribed by Royal Enfield in this Owner's manual and warranty repairs if any, has been carried out at the Authorized Distributor's service facility OR at their Authorized dealership's service facility.
- 3. The warranty shall be applicable only if all the services are availed in the respective period / kilometer ranges as per the schedule in the owner's manual from RE Authorised Dealer / Service Centre.
- 4. During the warranty period, RE's obligations shall be limited to repairing / replacing part(s) of the motorcycle for free, only if the part(s), on examination is deemed to have a manufacturing defect. Defective part(s) which have been replaced will become the sole property of RE.
- Consumables like Oil, Oil Filter, Fuel etc. used during warranty repair / replacement are not covered and chargeable to the customer.

124	Royal Enfield Himalayan	
124	Royal Ellileiu Hillialayali	

WARRANTY TERMS & CONDITIONS

- 6. Claims on proprietary items like tyres, tubes, spark plug, battery etc. should be taken up with the respective manufacturer or their authorised agents in the area directly by the customer. RE shall not be liable in any manner to replace them through their dealers. RE will, however, provide assistance in referring such claims on the respective manufacturer.
- 7. Warranty shall not apply to:
 - (a) Normal ageing, deterioration or rusting of plated parts, paints coat, rubber parts, soft items, glass items, plastic parts etc.
 - (b) Components like fuel filter, oil filter, air filter paper element, control cables, brake shoes / brake pads, clutch plates, drive chain & sprocket kit, steering ball races, electrical equipment, wiring harness etc., which are subjected to normal wear and tear.
 - (c) Failures occurred due to use of non recommended grade lubricants, fuel or improper level.
 - (d) Damages due to use of non-genuine parts, lack of proper maintenance, incorrect riding habits.
 - (e) Damages to engine management system parts (like ECU, Throttle body, Sensors, etc.) due to tampering which affects the performance of the motorcycle.
 - (f) Parts damaged due to accidents, collision, abuse etc.
 - (g) Irregularities not recognised as affecting the quality or function of the motorcycle such as slight vibration.

 Oil leakage, discoloration of exhaust pipe bend and cat region / silencer / soft or hard shockabsorber etc.

WARRANTY TERMS & CONDITIONS

- (h) Warranty is not applicable for discoloration of Exhaust Pipe & Silencer, as it is a natural process that will happen during usage.
- (i) Defects arising from fitment of unauthorised or additional electrical loads.
- (j) Motorcycle serviced or repaired at unauthorised service centres.
- (k) Motorcycle used for competitions / racing / Stage Rallying etc.
- (I) Electrical component like bulbs, fuses etc. and electronic components failure due to repairs by arc welding.
- (m) Normal maintenance operations like adjustment of brakes, cleaning fuel system, engine tune-up and other such adjustments.
- (n) Oxidization of buffed / painted / powder coated items etc.
- 8. Use only Royal Enfield approved parts and accessories. Use of certain other manufacturer's performance parts will void your new motorcycle warranty.
- 9. RE reserves the right to finally decide on all warranty claims.
- $10. \ \ RE\ reserves\ the\ right\ to\ make\ changes\ in\ design\ of\ the\ motor cycle\ without\ any\ obligation\ to\ install\ these\ changes\ on\ previously\ supplied\ motor cycles.$

This emission warranty is valid for 30,000 Kms / 3 years from the date of first sale whichever earlier, to the first customer and is in addition to and parallel to the warranty policy, conditions and obligations laid down in the Owner's Manual.

Royal Enfield further warrants that if on examination by its Royal Enfield Authorised Service Centre, the motorcycle fails to meet the specified emission standards, then the Authorised Service Centre shall take necessary corrective measures and shall, at its sole discretion, repair or replace free of charge components of the emission control system to meet the required emission standards.

The method/s of examination to determine the warranty conditions of the emission warranty related components will be at the sole discretion of Royal Enfield and / or our Authorised Service Centre and results of such examination will be final and binding. If on examination the warranty conditions of the part/s is/are not established, Royal Enfield will have the right to charge all, or part of the cost of such examination to the customer in addition to the cost of the components.

In case of acceptance of the component/s under Emission warranty, Royal Enfield will replace free of charge the component/s as required. However, the consumables like fuel, lubricants, solvents, etc. shall be chargeable to the customer as per actuals.

In case any of the components covered under emission warranty or the associated parts are not independently replaceable. Royal Enfield will have the sole discretion to replace either the entire assembly or parts of the assembly through suitable repairs.

Royal Enfield reserves the right to carry out necessary consequential repairs to the motorcycle or replace any part, in addition to the repair or replacement of the components covered under emission warranty, to establish compliance to in-use emission standards. Such repairs / replacements will be chargeable to the customer.

All parts removed for replacement under warranty will become the property of Royal Enfield.

Royal Enfield will not be responsible for the cost of transportation of the motorcycle to the nearest Authorised Service Centre or for any loss due to non availability of the motorcycle during the period of examination and repairs by Royal Enfield and / or their Authorised Service Centre.

Royal Enfield will not be responsible for any penalties that may be charged by statutory authorities on account of failure to comply with the in-use emission standards.

The cost incurred to check emission of the motorcycle will have to be borne by the customer.

Emission warranty will be applicable irrespective of the change of ownership of the motorcycle provided all the conditions as laid down in this document are met from the date of original sale of the motorcycle.

THE WARRANTY SHALL APPLY IF THE CUSTOMER

- Observes all the important instructions and any other precautions listed in the owner's manual.
- Under all circumstances uses lubricants and fuel as recommended by Royal Enfield.
- Regularly obtains and carries out maintenance in accordance with Royal Enfield guidelines and enters the details in the Log book.
- Immediately approaches the nearest RE Authorised Dealer / Service Centre upon discovery of failure to comply with the emission standard inspite of having maintained and used the motorcycle in accordance with the instructions in the owner's manual and having carried out such repairs and adjustments as may be required with a view to establish such compliance.
- Production of a valid Pollution Under Control Certificate is necessary to claim Emission Warranty.
- Produces the owner's manual and Log book for verification details.
- Produces receipts covering maintenance of the motorcycle is specified in the owner's manual from the date of original purchase of the motorcycle.
- Produces valid certificate of Insurance and RTO Registration Certificate (R.C. Book).

THE EMISSION WARRANTY SHALL NOT APPLY IF

- A valid "Pollution under control" certificate is not produced.
- The motorcycle is not serviced by RE Authorised Dealer / Service Centre as per the service schedule described in the maintenance chart.
- The motorcycle has been subjected to abnormal use, abuse, neglect and improper maintenance or has met with an accident.
- Replacement parts not specified and approved by Royal Enfield have been used.
- The motorcycle, or parts there of, has been altered, tampered with or modified or replaced in an unauthorised manner.
- The odometer is not functioning or the odometer and / or its reading has been changed / tampered with, so that the actual distance covered cannot be readily determined.
- The motorcycle has been used for competitions, races and rallies or for the purpose of establishing records.
- On examination by Royal Enfield or its Authorised Dealer / Service Centre, if the motorcycle shows that any of the conditions stipulated in the Owner's manual with regard to use and maintenance have been violated.
- The motorcycle has been run on adulterated / leaded fuel or lubricant other than those specified by Royal Enfield in the Owner's manual or any other document given to the customer at the time of sale of the motorcycle.
- The emission related components are tampered with.

- All service and parts related bills and vouchers incurred during the tenure of the emission warranty is not produced.
- All maintenance activities carried out on the motorcycle during the tenure of the emission warranty are not entered in the log book.

TIPS TO BE ON THE RIGHT SIDE OF LAW

- Always get your motorcycle checked to meet the emission regulations through an authorised emission checking centre.
- Always carry a valid "Pollution Under Control" certificate with you, as and if applicable by law.

TIPS TO REDUCE POLLUTION

- Ensure that the periodical maintenance is carried out as stipulated in the owner's manual through a Royal Enfield Authorised Service Centre.
- Use only Unleaded petrol (91 RON or higher) from reputed fuel pumps.
- Ensure the fuel used is not adulterated.
- Use correct spark plug as recommended in the owner's manual.
- Use lubricants as per recommendations given on grade / brand in the owner's manual.

EVAPORATIVE EMISSION CONTROL SYSTEM WARRANTY

The following warranty applies to the evaporative emission control system.

Royal Enfield Motors warrants the first owner and each subsequent owner, that this motorcycle is designed and built so as to conform, at the time of sale, with applicable regulations specified by the evaporative emission control system related parts fitted to this motorcycle are free from defects in materials and workmanship which may cause this motorcycle not to meet applicable regulations period of 24 Months from the date of first use of the motorcycle.

The Warranty period shall begin either on the date the motorcycle is delivered to the first retail purchaser OR from the first date the motorcycle is used as a demonstrator OR as a display and/or trial motorcycle.

THE FOLLOWING ARE NOT COVERED BY THE EVAPORATIVE EMISSION CONTROL SYSTEM WARRANTY:

1.	Failures which may arise as a result of misuse, alterations, accidents OR non performance of routine maintenance, a
	specified in the Owner's Manual.

EVAPORATIVE EMISSION CONTROL SYSTEM WARRANTY

- 2. Replacing OR removing OR modifying any portion of the EVAPORATIVE EMISSION CONTROL SYSTEM (consisting of Fuel tank, fuel tank cap, Canister, purge valve, throttle body, vapor hoses, fuel hoses and hose connectors) with parts not certified to be genuine.
- 3. Loss of time, inconvenience, loss of motorcycle use or any other consequential loss or damages.
- 4. Any motorcycle in which the Odometer has been tampered with, OR the Speedo cable has been disconnected for any reason OR is broken and not replaced immediately, due to which the exact distance covered cannot be determined.
- 5. Normal ageing of parts such as fuel hoses, vapor hoses, gaskets & rubber components.

RECOMMENDATIONS FOR REQUIRED MAINTENANCE:

IT IS RECOMMENDED THAT THE ROUTINE MAINTENANCE OF THE MOTORCYCLE BE CARRIED OUT AT SPECIFIED INTERVALS AND ANY MAINTENANCE TO THE EVAPORATIVE EMISSION CONTROL SYSTEMS SHOULD BE PERFORMED ONLY BY AN AUTHORISED ROYAL ENFIELD SERVICE DEALER AND USING ONLY GENUINE ROYAL ENFIELD SPARE PARTS.

SERVICE/MAINTENANCE RECORD

S.No.	Date	Job Card No.	KMS/ Miles	Brief details of work / service	Royal Enfield Authorized Dealer
1.					
2.					
3.					
4.					
5.					
6.					
7.					

SERVICE/MAINTENANCE RECORD

S.No.	Date	Job Card No.	KMS/ Miles	Brief details of work / service	Royal Enfield Authorized Dealer
8.					
9.					
10					
11.					
12.					
13.					
14.					

NOTES



Part No. RAM00264/A

ROYALENFIELD.COM